




ISP Network Management Guide




Part No. 1.024.1987-00
Version 1.0



ISP Network Management Guide

<http://www.3com.com/>

Part No. 1.024.1987-00



3Com Corporation
5400 Bayfront Plaza
Santa Clara, California
95052-8145

Copyright © 1998, 3Com Corporation. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty of any kind, either implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

UNITED STATES GOVERNMENT LEGENDS:

If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:

United States Government Legend: All technical data and computer software is commercial in nature and developed solely at private expense. Software is delivered as Commercial Computer Software as defined in DFARS 252.227-7014 (June 1995) or as a commercial item as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

[Portions of this documentation are reproduced in whole or in part with permission from (as appropriate).]

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com and the 3Com logo are registered trademarks of 3Com Corporation.

Microsoft, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation. UNIX is a registered trademark of X/Open Company, Ltd. in the United States and other countries.

Other brand and product names may be registered trademarks or trademarks of their respective holders.

YEAR 2000 INFORMATION:

For information on Year 2000 compliance and 3Com products, visit the 3Com Year 2000 web page:

<http://www.3Com.com/products/yr2000.html>

CONTENTS

ABOUT THIS GUIDE

Conventions	5
Related Documentation	6
Contacting 3Com	6

ISP NETWORK MANAGEMENT GUIDE

Important General Advice	9
Become Proactive	9
Keep Current Records	9
Provide Technicians with the Right Tools and Training	10
Tools Overview	10
Total Control Manager	10
HiPer DSP Console	11
HiPer ARC Console	11
NETServer Console	12
Security / Accounting Server	12
Other Tools	13
Techniques Overview	13
Documenting the System	15
Inventory	15
Configuration Capture	16
Passive Monitoring	19
Traps	19
Accounting	20
Active Monitoring	24
Using Total Control Manager Software	24
HiPer DSP	25
26	
Using HiPer DSP AT Commands	31
Quad Modems	34
Dual T1/PRI	34

Investigating Problems	36
Chassis	36
Quad Modems	36
HiPer DSP	37
HiPer ARC	39
NETServer	40
PPP System	42
RADIUS System	44
Tools	46
Correcting Problems	48
Span Alarms	48
Telco Loopback Testing	49
Dual PRI	49
HiPer DSP	49
Quad Modem	50
NETServer	50
x2 and V.90 Troubleshooting	51

APPENDIX

NETServer Debug Settings	53
--------------------------	----

INDEX

ABOUT THIS GUIDE

About This Guide provides an overview of this guide, describes guide conventions, tells you where to look for specific information and lists other publications that may be useful.

This guide describes network management techniques for Internet service providers (ISPs).

Conventions

These tables list conventions used throughout this guide.

Icon	Notice Type	Description
	Information note	Information that contains important features or instructions.
	Caution	Information to alert you to potential damage to a program, system, or device.
	Warning	Information to alert you to potential personal injury or fatality. May also alert you to potential electrical hazard.
	ESD	Information to alert you to take proper grounding precautions before handling a product.

Convention	Description
Commands	<p>The word “command” means you must enter the command exactly as shown in text and press the Return or Enter key. Example:</p> <p>To remove the IP address, enter the following command:</p> <pre>SETDefault !0 -IP NETaddr = 0.0.0.0</pre> <p><i>This guide always gives the full form of a command in uppercase and lowercase letters. However, you can abbreviate commands by entering only the uppercase letters and the appropriate value. Commands are not case-sensitive.</i></p>

Convention	Description
Screen displays	This typeface represents information as it appears on the screen.
The words "enter" and "type"	When you see the word "enter" in this guide, you must type something, and then press the Return or Enter key. Do not press the Return or Enter key when an instruction simply says "type."

Related Documentation

The Total Control Hub Documentation Library is an excellent source of detailed information about the chassis. The library is available on CD-ROM and on our web site.

- Total Control Enterprise Network Hub Documentation Library, System Release 3.1, part number 1.035.0008-02.
- Web site: <http://totalservice.3com.com>

Contacting 3Com

Call the appropriate toll free number listed below for technical support.



For European countries that do not have a toll free number listed, call +31 30 602 9900.

Country	Toll Free Number	Country	Toll Free Number
Austria	06 607468	Netherlands	0800 0227788
Belgium	0800 71429	Norway	800 11376
Canada	1800 2318770	Poland	00800 3111206
Denmark	800 17309	Portugal	0800 831416
Finland	0800 113153	South Africa	0800 995014
France	0800 917959	Spain	900 983125
Germany	0800 1821502	Sweden	020 795482
Hungary	00800 12813	Switzerland	0800 553072
Ireland	1800 553117	UK	0800 966197
Israel	0800 9453794	United States	1800 2318770
Italy	1678 79489	All Other Locations (Outside Europe)	1847 7976600

Refer to the Total Control Hub Documentation CD-ROM for more information regarding product warranty.



For information about Customer Service, including support, training, contracts, and documentation, visit our website at
<http://totalservice.3com.com>



ISP NETWORK MANAGEMENT GUIDE

This guide introduces and explains the monitoring and troubleshooting tools that are associated with the Total Control multiservice access platform. In addition, it provides general advice regarding documenting chassis and network configuration to ease troubleshooting.

Important General Advice

To increase the uptime of your network, strive to make progress in these three areas: anticipating problems by monitoring proactively, keeping current configuration records, and providing technicians with the proper tools and training.

Become Proactive

Many ISPs find themselves caught in a reactive mode when it comes to problem resolution. Network issues are addressed only when customers complain about them.

Ideally, you will anticipate network problems and head them off before customers complain. The best way to do that is by adopting proactive, passive monitoring methods. A substantial portion of this guide explains how to do that.

Keep Current Records

As you isolate problems, it is essential that you have recent records of known-good equipment configurations. That way, you have valid configuration data against which to compare problematic ones.

It is best to perform inventories every couple of months and to save the results in an easily accessible location, preferably online. The Inventory function in Total Control Manager is ideal for gathering configuration data.

Additionally, you can use an accounting server to collect performance and network status data that will be useful when you isolate problems. This guide also explains how to do that.

Provide Technicians with the Right Tools and Training

All network technicians should have available to them a management information base (MIB) browser and an alarm server.

MIB browsers allow technicians to retrieve information and manipulate settings from network equipment using the simple network management protocol (SNMP), which is carried over the Internet protocol (IP).

Alarm servers, when connected to IP networks, notify users when SNMP “traps,” or alarms, are received from network equipment. The equipment must be preconfigured to issue traps when threshold values of certain key measures are reached.

All network technicians should have a firm grounding in the workings of the IP stack and in managing network equipment using SNMP.

Tools Overview

The Total Control multiservice access platform provides many tools for assessing its status and for troubleshooting.

Total Control Manager

Total Control Manager is a stand-alone SNMP-based management application that is dedicated to Total Control hubs. Total Control Manager provides a number of tools that can be used to monitor, configure, and troubleshoot.

Virtual Front Panel Display

Total Control Manager provides a view of the Total Control chassis front panel, which allows you to view its LEDs remotely.

Performance Monitor / Session Monitor

Performance Monitor (called Session Monitor in Total Control Manager for Windows) is the key tool for gathering performance data from the Total Control hub during operation.

Inventory

The Inventory function gathers information from the chassis and installed cards, including hardware and software version numbers, amount of memory, and DIP switch settings. The results of the inventory can be saved as a text file.

Trap (Alarm) and Accounting Configuration

Use Total Control Manager to set up the chassis to send alarms and accounting data automatically to an alarm server or an accounting server, respectively. Doing so is vital to a proactive approach to chassis management.

HiPer DSP Console

Access the HiPer DSP console interface by connecting a computer (running terminal emulation software) to the Console port in its T1/E1 Network Interface Card (NIC).

Span Statistics

The *display spnstats debug* command provides detailed information about the T1 or PRI span status, including any alarms on the span, counts of various error conditions, number of calls received versus accepted, switch type, and D-channel status.

Timeslot and Protocol Status

The commands *display atstat* and *display atproto* give the status of each timeslot (DS0) of the span and the protocol each modem is using to communicate with remote modems.

Line Errors

The *display near current* and *display near total* commands show counts of errors received on the T1 or PRI span in the last 15 minutes and 24 hours, respectively.

Disconnect and Call Failure Reasons

Using the *AT-ADn* and *AT-AFn* commands, you can view the past *n* call disconnect and call failure reasons, respectively.

Protocol Tracing

You can trace aspects of the HiPer DSP's functioning in minute detail using the trace debug (*trc dbg*) command.

HiPer ARC Console

Access the HiPer ARC's console interface either locally, from a computer (running terminal emulation software) connected to its Ethernet NIC console port, or remotely by telnetting to the HiPer ARC IP address.

PPP Monitor

Point-to-Point Protocol (PPP) Monitor is useful for examining the PPP negotiation process from the HiPer ARC's point of view.

RADIUS Monitor

Remote Authentication Dial-In User Service (RADIUS) Monitor is useful for examining the RADIUS authentication or accounting process from the HiPer ARC's point of view.

SYSLOG

SYSLOG allows you to track every event that occurs at the HiPer ARC, in exhaustive detail if necessary. Events can be logged to a SYSLOG server or displayed to the console or telnet session.

NETServer Console

The NETServer provides useful tools for problem solving. Access its console interface locally, from a computer (running terminal emulation software) connected to its Ethernet NIC console port, or remotely by telnetting to the NETServer IP address.

Packet Bus / Modem Status

The fundamental NETServer command, *show all*, gives the status of the modems and their connections to the packet bus.

Debug

The *set debug* command causes protocol details to display on screen for further analysis.

Security / Accounting Server

3Com's Total Control Security and Accounting Server performs RADIUS authentication and accounting services. Its configuration files are vital for troubleshooting.

Log File

The **security.log** file is helpful for troubleshooting.

Windows Client

The Windows version of the Security and Accounting Server ships with **client.exe**, a program that simulates a RADIUS client (such as HiPer ARC or NETServer) and is very useful for testing.

Other Tools These third-party, freeware, and unsupported-3Com tools aid troubleshooting.

Snoop / Tcpdump

Snoop and Tcpdump are IP analyzers for UNIX; Snoop runs on Sun systems and Tcpdump is a freeware program with versions for most any UNIX variant.

NETMON (Event Viewer)

NETMON is a protocol analyzer that ships with Windows NT, but is not installed by default. The version included with Microsoft Systems Manager Server (SMS) captures any packets it detects, but the standard Windows NT version captures only packets sent from or received by the computer on which it is running.

Windows PPP and Modem Logs

Windows 95/98 clients are capable of generating logs of PPP negotiation (through Dial-Up Adapter) and modem activity (through Dial-Up Networking).

Unsupported 3Com Protocol Decoders

These applications were written by 3Com technical support personnel and are not officially supported by 3Com. Among them is RADDEBUG, for decoding RADIUS packets.

Techniques Overview

The remainder of this document explains:

Documenting the system A key to easing troubleshooting is ready access to known-good configuration data. This section explains how to gather it using Total Control Manager.

Passive monitoring This section explains how to set up the Total Control hub (using Total Control Manager) to provide automatic notification of specified events and to send accounting data automatically to a logging server.

Active monitoring Active monitoring is the process of examining the system when there is not necessarily any indication of trouble.

Investigating problems In this case, there is a symptom of trouble, such as user reports of connection problems or network slowness. This section offers techniques for finding the cause.

Correcting problems Problems described in this section have a clear symptom and a straightforward fix.

x2 troubleshooting Provides a reference to another document on this subject.

Documenting the System

Document chassis configurations at least quarterly, and preferably every two months.

Inventory

A simple way to document the physical configuration is to use the Inventory function in Total Control Manager. Inventory gathers:

- Network Application Card (NAC) and NIC names and serial numbers
- Software revisions
- Amount of memory
- DIP switch settings

Inventory does not record software settings.

Inventorying a Chassis

- 1 Start Total Control Manager.
- 2 If you have managed the chassis before from this workstation, from the **File** menu, click **Open**, choose the desired chassis from the list, and then click **OK**.
If you have not managed the chassis before from this workstation, from the **File** menu, click **New**, enter a name for the chassis, the IP address you assigned to the Network Management Card (NMC), plus SNMP community strings (passwords) if you entered them. Then click **OK**.
- 3 When the chassis appears, from the **Configure** menu, click **Inventory**.
- 4 Select the chassis from the list, then click **OK**. The inventory appears.

5 Click **Save** to save the inventory to a text file. The output looks like this:

```
U.S. Robotics 17-Slot Chassis with PB clocking
MyLabChassis <x.x.250.125>

1 3COM PRI-T1/E1 NACBCG53F2I2.0.0 40961024 00000000000001003.0.2
2 3COM Qd V.34 D-A Mdm NACB1G656B10P70002.0.0 0 000000001100010005.9.9
3 3COM Qd V.34 D-A Mdm NACB1G656BN0P70002.0.0 0 000000001100010005.9.9
4 3COM Qd V.34 D-A Mdm NACB8R68JEZ10T0002.0.0 0 000000001100010005.10.9
5 3COM Qd V.34 D-A Mdm NACB8R68JFG10T0002.0.0 0 000000001100010005.10.9
6 3COM Qd V.34 D-A Mdm NACB8R68JEB10T0002.0.0 0 000000001100010005.10.9
7 3COM H-D 24 Ch NAC56789ABC0.49.0 81922048000000000000000001.2.5
16 3COM ISDN NETServer NACBA27TPFX17C0007.0.0163844096 00000000000000000.8.1
17 3COM NMC with clockBBO78OIP1U60006.016384819200000000000000005.5.5
1 3COM LongHaul Dl T1 NIC 40961024000000000000000100
2 3COM Qd Mdm Anlg NIC v1 0 000000001100010001.1.0
7 3COM T1/E1 HDM NIC 81922048000000000000000000
16 3COM HS Enet (V.35) NIC1638440960000000000000000000
17 3COM Ethernet NIC?????????? 0 000000000000000000
```

Configuration Capture

This manual method captures all the software settings for all the cards except the gateways (HiPer ARC or NETServer). It involves stepping through all the configurable parameters for each card in Total Control Manager, copying them, and pasting them into a spreadsheet.

To capture the configuration of all cards except gateways

- 1 Start Total Control Manager.
- 2 If you have managed the chassis before from this workstation, from the **File** menu, click **Open**, choose the desired chassis from the list, and then click **OK**.

If you have not managed the chassis before from this workstation, from the **File** menu, click **New**, enter a name for the chassis, the IP address you assigned to the Network Management Card (NMC), plus SNMP community strings (passwords) if you entered them. Then click **OK**.
- 3 When the chassis appears, click the leftmost card (for example, the Dual PRI NAC).
- 4 From the **Configure** menu, click **Programmed Settings**.
- 5 Select the first menu item that contains user-configurable parameters (for example, PRI Configuration).

- 6 Click the upper-left cell of the table.

	S1
Line A Timing Source	high
Line B Timing Source	mediumHigh
Internal Timing Source	notAllowed
ISDN-GW Slot	16
Analog Modem Calls	enable
Modem call routing method	roundRobin
Set DSO Out of Service upon NAC	disable
INFO Message Timeout	12
DNIS Length	15
Select PCM Companding	ulaw

- 7 Press [Ctrl] + [c] to copy the table to the clipboard.
- 8 Start a spreadsheet program, such as Microsoft Excel, and create a new spreadsheet.
- 9 Name the first page of the spreadsheet (for example, Dual PRI).
- 10 Select the first cell on the page, then press [Ctrl] + [v] to paste the cells into the spreadsheet.
- 11 Adjust the cell widths to fit the text.

The result is an exact copy of the Parameter Group.

	A	B
1		S1
2	Line A Timing Source	high
3	Line B Timing Source	mediumHigh
4	Internal Timing Source	notAllowed
5	ISDN-GW Slot	16
6	Analog Modem Calls	enable
7	Modem call routing method	roundRobin
8	Set DSO Out of Service upon NAC Removal	disable
9	INFO Message Timeout	12
10	DNIS Length	15
11	Select PCM Companding	ulaw

- 12 Repeat steps 4–11 until you have captured all user-configurable parameters for the first card.
- 13 [Optional.] From the Fault menu, select Trap Settings and then repeat steps 5–12.

- 14 [Optional.] From the Fault menu, select Trap Destinations and then repeat steps 5–12.
- 15 Start a new page in the spreadsheet and name it (for example, Quad Modem).
- 16 Repeat steps 4–15 until you have captured all user-configurable parameters for all the cards (except the gateway cards).

To capture a NETServer configuration

- 1 From a NETServer command prompt, enter
`show net0`
- 2 Enter
`show global`
- 3 Enter
`show all`
- 4 Select the results of these commands, copy them, and save them.

To capture a HiPer ARC configuration

- 1 From a HiPer ARC command prompt, enter
`show config`
- 2 Select the result of this command, copy it, and save it.

Passive Monitoring

Use Total Control Manager to set up automatic notification of problems and automatic logging of accounting data.

To provide automatic notification of problems, the Network Management Card (NMC) issues SNMP traps. To log accounting data automatically, the NMC sends RADIUS accounting messages. In each case, you must configure a device to receive the messages.

Traps Alarm notification requires two components: a device (the Total Control chassis) to issue traps and a device to receive them and alert the network manager (an alarm server). The protocol behind this is the Simple Network Management Protocol (SNMP), which runs on the User Datagram Protocol / Internet Protocol (UDP/IP).

To tell the NMC where to send traps

- 1 Select the **NMC**.
- 2 From the **Fault** menu, click **Trap Destinations**.
- 3 Click **Add**.
- 4 Type the IP address of the alarm server and its community string (password).
- 5 Click **OK**, then click **Exit**.

To enable the NMC to send traps

Several important chassis-level events send traps by default, such as card insertion and removal, power supply failure, and high temperature.

- 1 Select the **NMC**.
- 2 From the **Fault** menu, click **Trap Settings**.
- 3 From Parameter Group, select **Chassis Trap Enables**.

Change all the events in this list from enableTrap to enableAll. This requests that, in addition to a trap, the event is logged in the accounting server. See the next section for more information.

Enable traps from specific cards for infrequent, high-impact events such as DS1 red alarms, loss of signal, loss of D-channel. For example, to enable such traps in the HiPer DSP:

- 1 Select the span LEDs on the HiPer DSP.
- 2 From the **Fault** menu, click **Trap Settings**.

- 3 From Parameter Group, select **Trap Enables**.

Enable traps and log (see next section) for several of these events, including On Red Alarm and On Loss of Signal.

If this is a PRI line, from Parameter Group, select **D-Channel Service Traps** and enable **On D-Channel Out of Service**.

Traps can also aid troubleshooting. When warranted, enable traps to help isolate problems.

Accounting

When you enable accounting, events that you specify are logged quietly to an accounting server. You can retrieve and examine the records whenever you choose.

As with alarms, two components are required: a device (the Total Control hub) to issue the accounting messages and a device to receive and log them (an accounting server). The protocol behind this is Remote Authentication Dial-In User Service (RADIUS), which runs on UDP/IP.

For the most effective records, generate an accounting record every time a call fails.

Before continuing, make sure you have the Accounting Server installed.

To tell the NMC where to send accounting messages

- 1 Select the **NMC**.
- 2 From the **Configure** menu, click **Programmed Settings**.
- 3 From Parameter Group, select **Logging Group**.
- 4 At Primary Log Server IP Address, type the IP address of the accounting server. Add backup server IP addresses as necessary. Click **Set**, then click **OK**.

Enable these accounting messages for HiPer DSP

- 1 Click the body of the HiPer DSP card.
- 2 From the **Fault** menu, click **Trap Settings**.
- 3 Click **ALL** (use ALL templates), then click **OK**.
- 4 From Parameter Group, select **Trap Enables**.

- 5 Select **enableLog** for:
 - On Incoming Call
 - On Incoming Termination
 - Incoming Connection Attempt Failure
- 6 Click **OK**.
- 7 Click the span LEDs of the HiPer DSP.
- 8 From the **Fault** menu, click **Trap Settings**.
- 9 From Parameter Group, select **Trap Enables**.
- 10 Select **enableAll** for all events.



Select **enableAll** only if there is a trap server to which to send the traps. If not, select **enableLog**.

Enable these accounting messages for Dual T1/PRI

- 1 Click the body of the Dual T1/PRI card.
- 2 From the **Fault** menu, click **Trap Settings**.
- 3 From Parameter Group, select **Trap Enables**.
- 4 Select **enableLog** for:
 - On Call Arrive
 - On Call Connect
 - On Call Termination
 - On Call Failure
- 5 Click **OK**.
- 6 Click the top LED of the Dual T1/PRI card.
- 7 From the **Fault** menu, click **Trap Settings**.
- 8 From Parameter Group, select **Trap Enables**.
- 9 Select **enableAll** for all events.



Select **enableAll** only if there is a trap server to which to send the traps. If not, select **enableLog**.

Enable these accounting messages for Quad Modems

- 1 Select the top LED of the Quad Modem card.
- 2 From the **Fault** menu, click **Trap Settings**.

- 3 From Parameter Group, select **Trap Enables**.
- 4 Select **enableLog** for:
 - On Incoming Call
 - On Incoming Termination
 - On Connection Failure

To set logging groups for the NMC

Logging groups are filters for the data the NMC sends to an accounting server when an event occurs. The logging group settings for the NMC affect all cards in the chassis except HiPer DSP.

When an event occurs that generates a trap or an accounting record, the card sends all the data over the management bus to the NMC, but the NMC filters it and sends what you specify according to logging group. The groups are explained fully in the NMC Parameter Reference manual.

Table 1 Descriptions of logging groups

Group number	Description
1	Usage statistics [always sent]
2	Data transfer statistics
3	Performance statistics
4	Operating mode statistics
5	Remote Modem Management Information Exchange (RMMIE)

- 1 Click the NMC.
- 2 From the **Configure** menu, click **Programmed Settings**.
- 3 From Parameter Group, select **Logging Group**.
- 4 For Log Group Selection, select **group2345 (ALL)**.

To set logging groups for the HiPer DSP

The HiPer DSP logging group setting overrides that of the NMC.

- 1 Click the body of the HiPer DSP.
- 2 From the **Configure** menu, click **Programmed Settings**.
- 3 Click **Card Level**, then click **OK**.

- 4 From Parameter Group, select **Call Statistics**.
- 5 From Group Settings, select a logging group.

Enable these accounting messages for the TC chassis

- 1 Click the NMC.
- 2 From the **Fault** menu, click **Trap Settings**.
- 3 From Parameter Group, select **Chassis Trap Enables**.
- 4 Change them all to **enableAll**. This produces a record at the accounting server.

Active Monitoring

Monitor actively by using Total Control Manager or card console interfaces to scan the system.

Using Total Control Manager Software

To scan LEDs for faults

When you open a chassis in Total Control Manager, the virtual front panel display (VFPD) appears. The LEDs on the front of the chassis are updated in nearly real-time.

Important LEDs to watch:

Hub Status LED (second one down on NMC)

- Solid RED indicates a critical failure in the chassis.
 - Check the hub status: click the NMC, then from the **Performance** menu, click **Session Monitor**. From Functional Group, select **Failure Reasons**. From Parameters, select **Hub Status Red**. Click **Add**, then click **OK**.
 - Look for bootup failures: click the NMC, then from the **Configure** menu, click **Programmed Settings**. From Parameter Group, click **NMC Tests**.
 - Check chassis temperature: click the NMC, then from the **Configure** menu, click **Programmed Settings**. From Parameter Group, click **NMC Identification**. The Ideal temperature range 24–25° C. Be concerned if the temperature exceeds 40° C.
 - Check for stopped fans (must visit the chassis).
 - Check accounting or trap logs for failures.
 - A card that is resetting can cause this condition.
 - A PSU that has failed or is unplugged can cause this condition.
- Flashing RED indicates management bus failure.

Quad Modem LED If a modem is RED,

- And there's no NETServer in the chassis, as with Citrix WinFrame, the modem is not receiving the Data Terminal Ready (DTR) signal.

Make sure the RS-232 cables are connected and verify that your communications software is running and configured correctly.

- And there is a NETServer in the chassis, there's a problem with the packet bus or with the NETServer.

If a modem is ORANGE, the modem is training. Wait.

HiPer DSP **To monitor modem events**

- 1 Click the HiPer DSP modem LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Select the channels (modems) to monitor, then click **OK**.
- 4 From Functional Group, select **Modem Events**.
- 5 Select:
 - Incoming Connections Established
 - Incoming Connections Failed
 - Connect Attempt Failures

Then click **Add**, then click **OK**.



In Total Control Manager for UNIX, you can graph these results.

To check for continuous CRC errors

Indicates true/false.

- 1 Click span LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **DS1**, then click **OK**.
- 4 From Functional Group, select **Call Statistics**.
- 5 Click **Continuous CRC Errors**. Click **Add**, then click **OK**.

To check PRI D-channel status

Indicates up or down.

- 1 Click span LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **DS1**, then click **OK**.
- 4 From Functional Group, select **Call Statistics**.
- 5 Click **D Channel Operation**. Click **Add**, then click **OK**.

To check whether DS0s are in service

- 1 Select span LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **DS0**.
- 4 Click **Select All** (or select the DS0s you are interested in), then click **OK**.
- 5 From Functional Group, select **DS0 Statistics**.
- 6 Select **DS0 Service State**. Click **Add**, then click **OK**.

To check for excessive connect times

- 1 Select the modem LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **Select All** (or select the DS0s you are interested in), then click **OK**.
- 4 From Functional Group, select **Call Statistics**.
- 5 Select **Call Duration**. Click **Add**, then click **OK**.

Using the HiPer DSP Console Interface

Access the HiPer DSP console interface by connecting a cable from a computer's serial port to the Console port in the HiPer DSP T1/E1 NIC. The computer must run terminal emulation software at 9600 bps.

Issue these *display* commands from a *span* command prompt.

`display spnstats debug` This command provides detailed information about the span's status.

Key items to examine:

- *Span line status* details any alarm conditions the line is experiencing (this is physical layer).

```
Span1 Line Status is:
NO ALARM                = TRUE
RCV FAR END LOF         = FALSE
XMT FAR END LOF         = FALSE
RCV AIS                  = FALSE
XMT AIS                  = FALSE
OUT OF FRAME            = FALSE
LOSS OF SIGNAL          = FALSE
LOOPBACK STATE          = FALSE
T16 AIS                  = FALSE
RCV FAR END LOMF        = FALSE
XMT FAR END LOMF        = FALSE
RCV TEST CODE           = FALSE
OTHER FAILURE           = FALSE
```

- *Continuous CRC error*, true or false.

```
Span1 Continuous CRC Error is:                FALSE
```

- *Modem not available count* gives the number of calls that the span could accept, but found no modems to pass to. There is no active packet bus connection between at least one of the modems and a gateway card. Either the configuration is bad, the modem is dead, or there may be a bug.

At the gateway card, verify that the packet-bus sessions are active. (From the NETServer, send *show all*. From the HiPer ARC, send *list interfaces*.)

If the packet bus sessions are ok, in Total Control Manager, select all modems and bring up Performance Monitor. Look for one or more modems with an abnormal number of incoming failed connections.

From the modem channel with many failed connections, send AT-AFn to display call failure reasons. That may point to the source of the problem. AT-SR indicates whether a modem has “hung” or may have a hardware problem.

- High *Invalid...* or *Dial in no resp to disc* counts point to problems with the span, probably at the telco. These are errors in the Q.931 frame that you can investigate using tracing (see To examine Q.931 (D-channel) activity on page 37).

```
Span1 Modem Not Available Count is:      0
Span1 Invalid Bearer Capability Count is: 0
Span1 Invalid Channel ID Count is:      0
Span1 Invalid Progress Indicator Count is: 0
Span1 Invalid Calling Party Count is:   0
Span1 Invalid Called Party Count is:    0
...
Span1 Dial In No Resp To Disc Count is:  0
```

- Compare *Calls received* to *Calls accepted*; any difference indicates potential problems.

```
Span1 In Digital Calls Received Count is: 39
Span1 In Digital Calls Accepted Count is: 39
Span1 In Analog Calls Received Count is: 2336
Span1 In Analog Calls Accepted Count is: 2335
```

- *D-channel status*, up or down.

```
Span1 D-channel Operational is:          UP
```

To check the DS0 in-service status

display atstat This command allows you to view the status of the DS0s and each associated modem.

```
span1> di ats
```

Tslot	Status	Modem	Status	Call ID	Action	Q931
		Connect	Srvc State		Queued	Ref
01	Conn In	001	IS	0x08ED0002	NONE	0x0000034B
02	Idle	N/A	IS	0x00000000	NONE	0x00000000
03	Idle	N/A	IS	0x00000000	NONE	0x00000000
04	Conn In	004	IS	0x093F0302	NONE	0x0000039D
05	Conn In	005	IS	0x09050402	NONE	0x00000363
06	Conn In	006	IS	0x09140502	NONE	0x00000372
...						

To determine which modem protocols are in use

display atproto This command allows you to view protocols in use in each modem connection.

```
span1> di atp
```

Tslot	Status	Modem	Protocol
		Connect	
01	Conn In	001	V.42/V.42bis/N/A
02	Idle	N/A	N/A
03	Conn In	003	V.42/V.42bis/V.34
04	Idle	N/A	N/A
05	Idle	N/A	N/A
06	Conn In	006	V.42/V.42bis/V.34
...			

To display errors that arrived in last 15 min over the T1 or PRI

display near current This command allows you to view all errors that have arrived over the T1 or PRI line in the past 15 minutes.

```
span1> di near current
Span1 Near Current Line Index is:                0
Span1 Near Current Errored Seconds is:           0
Span1 Near Current Severely Errored Seconds is:  0
Span1 Near Current Severely Errored Framing Seconds is: 0
Span1 Near Current Unavailable or Failed Seconds is: 0
Span1 Near Current Controlled Slip Seconds is:   0
Span1 Near Current Path Coding Violations is:    0
Span1 Near Current Line Errored Seconds is:     0
Span1 Near Current Bursty Errored Seconds is:   0
Span1 Near Current Degraded Minutes is:         0
Span1 Near Current Line Code Violations is:     0
Span1 Near Valid Intervals is:                  96
```

To display errors that arrived in last 24 hours over the T1 or PRI

display near total This command allows you to view all errors that have arrived over the T1 or PRI line in the past 24 hours.

```
span1> di near total
Span1 Near Total Line Index is:                0
Span1 Near Total Errored Seconds is:           0
Span1 Near Total Severely Errored Seconds is:  0
Span1 Near Total Severely Errored Framing Seconds is: 0
Span1 Near Total Unavailable or Failed Seconds is: 0
Span1 Near Total Controlled Slip Seconds is:   0
Span1 Near Total Path Coding Violations is:    0
Span1 Near Total Line Errored Seconds is:     0
Span1 Near Total Bursty Errored Seconds is:   0
Span1 Near Total Degraded Minutes is:         0
Span1 Near Total Line Code Violations is:     0
```

Using HiPer DSP AT Commands

Issue these commands from a modem command prompt (*chdev mdm*).

To examine prior disconnect reasons

AT-ADn Substitute for *n* the number of disconnect reasons you would like displayed.

Normal disconnect reasons are:

- carrierLoss (expect just a small percentage of these)
- ds0Teardown
- dtrDrop
- escapeSequence
- inactivityTimeout
- loopLoss
- normalUserCallClear
- rcvdGatewayDiscCmd
- V.42DisconnectCmd

Other disconnect reasons may indicate trouble. Refer to the *Trouble Clearing Call Fails and Modem Disconnects* appendix in the HiPer DSP Reference manual for an explanation of disconnect reasons.

```
mdm24> at-ad3
```

```
(Ch.255): 11:22:50:184
```

```
Number of call disconnects since powerup is 2233.
```

```
(Ch.2): 11:22:50:184
```

```
Inbound call disconnect reason is Disconnect CMD.
```

```
(Ch.2): 11:22:50:184
```

```
Call start time 11:02:0426. Call duration 00:00:13.
```

```
(Ch.1): 11:22:51:009
```

```
Inbound call disconnect reason is Normal user call clear.
```

```
(Ch.1): 11:22:51:009
```

```
Call start time 11:02:0426. Call duration 00:00:22.
```

```
(Ch.6): 11:22:51:109
```

```
Inbound call disconnect reason is Received Disconnect command from  
Gateway Card.
```

```
(Ch.6): 11:22:51:109
```

```
Call start time 10:18:041. Call duration 00:45:06.
```

To examine prior call failure reasons

AT-AFn Substitute for *n* the number of call failure reasons you would like displayed.

Note that this is failure to achieve carrier between the two modems. Normal call failure reasons are:

- carrierLoss (expect just a small percentage of these)
- ds0Teardown
- normalUserCallClear

Others may indicate trouble. Refer to the *Trouble Clearing Call Fails and Modem Disconnects* appendix in the HiPer DSP Reference manual for an explanation of call failure reasons.

```
mdm24> at-af3
```

```
(Ch.255): 11:22:37:092
```

```
Number of failed calls since powerup is 129.
```

```
(Ch.15): 11:22:37:092
```

```
Inbound call failure reason is GSTN Cleardown Disconnect.
```

```
(Ch.15): 11:22:37:092
```

```
Call fail time 20:4:29.
```

```
(Ch.1): 11:22:37:117
```

```
Inbound call failure reason is Normal user call clear.
```

```
(Ch.6): 11:22:37:142
```

```
Call fail time 21:5:38.
```

```
(Ch.10): 11:22:38:017
```

```
Inbound call failure reason is No Carrier.
```

```
(Ch.10): 11:22:38:017
```

```
Call fail time 8:35:8.
```

Quad Modems To monitor modem events

- 1 Click the top LED for all modems, or a single modem LED.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 From Functional Group, select **Modem Events**.
- 4 Select these parameters:
 - Incoming Connections Established
 - Incoming Connections Failed
 - Connect Attempt Failure
- 5 Click **Add**, then click **OK**.



In Total Control Manager for UNIX, you can graph these results.

To check for excessive connect times

- 1 Click the top LED for all modems, or a single modem LED.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 From Functional Group, select **Call Statistics**.
- 4 Select **Call Duration**. Click **Add**, then click **OK**.

Dual T1/PRI To check CRC errors

- 1 Click the span LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **Span Line**, then click **OK**.
- 4 From Functional Group, select **Span Line Current Group**.
- 5 Select **Current Excess CRC Errors**. Click **Add**, then click **OK**.

To check PRI D-channel status

- 1 Click the span LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **Span Line**, then click **OK**.
- 4 From Functional Group, select **PRI Call Statistics**.
- 5 Select **D Channel Operational Status**. Click **Add**, then click **OK**.

To check DS0 status

- 1 Click the span LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **Timeslot**, then click **Select All** (or select the DS0s you are interested in). Click **OK**.
- 4 From Functional Group, select **Timeslot (DS0) Status**. Click **Add**, then click **OK**.

Table 2 DS0 status possibilities

Status	Description
Idle	No call is connected
Dialing	The modem associated with this DS0 is placing a call
Ring received	The modem associated with this DS0 is receiving a call
Link negotiation	The modems are training
Connected	The modems have detected carrier and have connected

If a DS0 is perpetually Idle, check the DS0 service state and make sure it is In Service.

To check DS0 In-service Status

- 1 Click the span LEDs.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 Click **Timeslot**, then click **Select All** (or select the DS0s you are interested in). Click **OK**.
- 4 From Functional Group, select **DS0 in service state status**. Click **Add**, then click **OK**.

Then check the gateway card packet bus sessions (NETServer: *show all*; HiPer ARC: *list interfaces*) to make sure they are active.

Investigating Problems

This section explains techniques for in-depth investigation when you suspect a problem.

Chassis Overheating

When the chassis overheats, the cards produce unusual events—incomplete calls, dropped calls, strange tones when dialing, or random card resets.

To check chassis temperature

- 1 Select the NMC.
- 2 From the **Performance** menu, click **Session Monitor**.
- 3 From Functional Group, select **Status Group**.
- 4 From Parameters, click **Chassis Temperature (.01 deg. C)**. Click **Add**, then click **OK**.

The Ideal temperature range is 24–25° C. Be concerned if the temperature exceeds 40° C.

Quad Modems To check DTE (bus) interface source

- 1 Click the top LED for all modems, or a single modem LED.
- 2 From the **Performance** menu, select **Session Monitor**.
- 3 From Functional Group, select **DTE Interface Settings**.
- 4 From Parameters, click **DTE Interface Source**. Click **Add**, then click **OK**.

To check line interface source

- 1 Click a modem (or top LED = all modems on card; or hold [Ctrl] and select multiple modems or top LEDs).
- 2 From the **Configure** menu, click **Programmed Settings**.
- 3 From Parameter Group, select **Line Interface Options**.
- 4 Line Interface Source indicates either t1Tdm, nic, or priTdm.

HiPer DSP To examine Q.931 (D-channel) activity

If the D-channel is down (and the physical layer is good), perform a Q.931 trace and watch for messages being exchanged between the HiPer DSP and the telco switching equipment.

- 1 Enable a trace of facility 25. Facility 25 is Q.931 signaling. Level 0 is off, level 1 is most detailed, and level 5 is least detailed.

```
span1> trc dbg 25 2  
Debug facility trace 25, level 2 activated
```

- 2 Disconnect the span from the jack at the HiPer DSP NIC. Wait five seconds.
- 3 Reconnect the span. Watch for messages for 30 seconds.

Messages on an active span look like this:

```
(Ch.0): 11:21:31:127  
TN RX0: len = 4 00 01 01 98  
  
(Ch.0): 11:21:37:122  
TN RX0: len = 9 02 01 F4 98 08 02 03 5A 75  
  
(Ch.0): 11:21:37:122  
TN TX0: len = 4 02 01 01 F6  
  
(Ch.0): 11:21:37:122  
TN TX0: len = 16 00 01 98 F6 08 02 83 5A 7D 08 02 80 9E 14
```

- 4 Turn off tracing.

```
span1> trc off  
Trace deactivated
```

- If no messages appear, the D-channel was probably disabled by the telco. Contact your telco.
- If messages appear, but the D-channel is still down (verify using *display d-chanop*), the switch type setting is probably incorrect.

To send a command to all 24 HiPer DSP modems at once

chmdm 255 Any command you send to modem 255 goes to all 24 modems at once.

```
mdm1> chmdm 255  
mdm255> ati4
```

To map all HiPer DSP modem bus interfaces to the AUX port

AT-SU99 This command disconnects all modems from the packet bus and maps their serial connections instead to the AUX PORT. All modems respond as one to commands.

Mapping serial connections to the AUX port is useful for isolating the modems. If they work correctly through the AUX port, the problem must be with other components of the system. Check the packet bus or gateway card.

```
mdm1> chmdm 255  
mdm255> at-su99
```

AT-SU100 After testing, send this command to map the modems' serial connections back to the packet bus.

```
mdm1> chmdm 255  
mdm255> at-su100
```



You may need to reboot the gateway card (HiPer ARC or NETServer) to restore the packet bus connections.

HiPer ARC Using HiPer ARC SYSLOG

HiPer ARC SYSLOG sends exhaustive data to the console interface, and optionally to a SYSLOG host or to a telnet session. Some examples of data you can log: call initiation process, IP, IPX, PPP, and SNMP.

For details about setting up SYSLOG, refer to the *Event Messages* appendix in the HiPer ARC Product Reference. For more detail, visit <http://interproc.ae.usr.com>.

show events Enter this command during a telnet session to cause the HiPer ARC to display SYSLOG data.

hide events Use this command to cease the display of SYSLOG data during a telnet session.

list facilities This command shows all the facilities you can have the HiPer ARC display.

set facility loglevel By default, all facilities are displayed at critical level—only critical events are displayed. Use this command to be more permissive about which events are displayed. You might change the log level, for example, if you suspect a particular facility as the cause.

```
set facility <"facility name"> loglevel <loglevel>
```

Send *list facilities* to view a list of facility names. If the facility name is more than one word, enclose the words in quotes.

Log Levels The log levels in order of increased information displayed:

- Critical
- Unusual
- Common
- Verbose

NETServer Issue this command from the NETServer's console interface, which is accessible by telnet or direct serial connection.

To check whether modems are connected to the packet bus

A typical symptom that occurs when modems are disconnected from the packet bus is a fast busy signal experienced by the caller.

show all This command gives the status of all the s-ports, which equate to serial connections to modems.

```
Command> sho all
```

```
Local Addr: x.x.250.126
```

```
Gateway: x.x.150.62
```

```
Netmask: 255.255.255.0
```

Port	Speed	Mdm	Host	Type	Status	Input	Output	Pend	
S0	9600	off		Login/Ne	USERNAME		0	27	0
S1	A I P	on	-	Netwrk	IDLE		0	0	0
S2	A I P	on	-	Netwrk	IDLE		0	0	0
S3	A I P	on	-	Netwrk	IDLE		0	0	0
S4	A I P	on	-	Netwrk	IDLE		0	0	0
S5	A R P	on	-	Netwrk	IDLE		0	0	0
S6	A R P	on	-	Netwrk	IDLE		0	0	0
S7	A R P	on	-	Netwrk	IDLE		0	0	0
S8	A R P	on	-	Netwrk	IDLE		0	0	0
S9	A R P	on	-	Netwrk	IDLE		0	0	0
...									

Interpreting the Speed Column

The Speed column provides information about the modems and their connections to the packet bus.

Packet bus activity The first field indicates whether the packet bus connection is configured as active or inactive.

Table 3 Packet bus activity

Indicator	Meaning
A	Active
I	Inactive

Packet bus connection status The second field reflects the actual status of the packet bus connection. It has four possible values:

Table 4 Packet bus connection status

Indicator	Meaning
A	Activating. The packet bus is forming the connection.
D	Disconnecting. The packet bus connection is being taken down.
I	Inactive. Either the port has been configured as Inactive or the modem has been physically disconnected.
R	Ready. The packet bus connection is up and ready.

Modem presence The third field indicates whether a modem is physically present:

Table 5 Modem presence

Indicator	Meaning
P	Modem present
?	Unidentifiable device present (can indicate transition between – and P)
–	Empty slot

set debug 0xnn *nn* is a hex value between 00 and FF.

Table 6 Useful debug settings (for a complete list see Appendix)

0x00	Ends debug
0x18	Logs route updates
0x51	PPP / LMI / Annex-D status
0x1200	Show packet destination, type, and length

set console The NETServer displays results to the console during a telnet session.

reset console Stops the flow of debug information.

PPP System HiPer ARC and NETServer, as well as Windows 95/98 clients, offer tools for PPP exploration.

To capture a PPP session using NETServer

- 1 From a NETServer command prompt, send the commands *set debug 0x51* and then *set console*.

```
Command> set debug 0x51
Setting debug value to 0x51
Command> set console
Setting CONSOLE to admin session
```

- 2 Capture the PPP session (save it as a text file).
- 3 Reset the console.

```
Command> reset console
Console RESET
```

- 4 Turn off debug.

```
Command> set debug 0x00
Setting debug value to 0x0
```

To capture a PPP session using HiPer ARC

- 1 From a HiPer command prompt, enter **monitor ppp**, or an abbreviation.

```
HiPer>> mon ppp
Hiper PPP Monitor

Select a letter for one of the following options:
```

- 2 Select one of the monitoring options from the list, depending on what exactly you are trying to figure out.
- 3 Press Esc to stop monitoring.
- 4 Capture the PPP session (save it as a text file).
- 5 Press Esc to end the session.
- 6 Press X to close PPP Monitor.

To diagnose problems with PPP negotiation

Usually a configuration issue, such as:

- A mismatch in addressing between server and client
- A bad IP pool on the HiPer ARC, NETServer, or RADIUS Server

To generate a modem event log with Windows 95/98

Compare this with the PPP negotiation data gathered from the HiPer ARC or NETServer.

- 1 Right-click the icon for the dial-up connection. From the menu that appears, select **Properties**.
- 2 From the **General** tab, click **Configure**.
- 3 Select the **Connection** tab, and then click **Advanced**.
- 4 From the Advanced Connection Settings dialog, select **Record a log file**.

When you make a call using Dial-Up Networking, Windows writes the modem events in the following file: **\windows\modemlog.txt**

To generate a PPP event log with Windows 95/98

Compare this record to the record from the HiPer ARC (*monitor ppp*) or NETServer (*set debug 0x51*).

- 1 From the Windows taskbar, click **Start**, then **Settings**, then **Control Panel**.
- 2 Double-click **Network**.
- 3 Click **Dial-Up Adapter**, then click **Properties**.
- 4 Click the **Advanced** tab.
- 5 For the property **Record a log file**, select the value **Yes**.

You must restart your computer before PPP logging will start.

When you make a call using Dial-Up Networking, Windows writes the PPP events in the following file: **\windows\ppplog.txt**

PPP Requests for Comments

Table 4 lists the PPP Requests for Comments (RFCs) that are relevant for debug.

Table 7 PPP Debug-Relevant RFCs

RFC #	Title
RFC 1661	The Point-to-Point Protocol (PPP)
RFC 1662	PPP in HDLC-like Framing
RFC 1334	PPP Authentication Protocols
RFC 1994	PPP Challenge Handshake Auth. Protocol (CHAP)
RFC 1332	The PPP IP Control Protocol (IPCP)
RFC 1552	The PPP IPX Control Protocol (IPXCP)
RFC 2097	The PPP NetBIOS Frames Control Protocol (NBFCP)
RFC 1990	The PPP Multilink Protocol (MP)
RFC 1700	Assigned Numbers



For more information, refer to Carlson, James: PPP Design and Debugging. Addison-Wesley Publishing Company; ISBN: 0201185393.

RADIUS System

Follow these steps to diagnose authentication problems between a HiPer ARC (which is a Remote Authentication Dial-In User Service [RADIUS] client) and a RADIUS server.



Keep in mind that the most common reason for authentication failure is an incorrect shared secret.

- 1 Determine whether you can ping the security server from the HiPer ARC. If not, perform standard IP troubleshooting. When you can ping the security server, proceed to the next step.

```
HiPer>> ping x.x.250.111
PING Destination: x.x.250.111 Status: ALIVE
```

- 2 Open two telnet sessions to the HiPer ARC.

Session 1: Run RADIUS monitor.

- a From a HiPer command prompt, enter **monitor radius**, or an abbreviation.

```
HiPer>> mon rad
HiPer RADIUS Monitor
```

```
Select a letter for one of the following options:
```

- b Select one of the monitoring options from the list, depending on what exactly you are trying to figure out.

Session 2: Run authentication test.

- c From a second telnet session, enter **_authenticate <username> <password>**. Do not type the angle brackets, but use a username and password that you are certain is in the RADIUS server database.

```
HiPer>> _auth userx xyz123
CLI - User: userx is Authenticated
```

- d Watch what happens in the first telnet session.

```
-----
Source-IP          Src-Port  Destination-IP  Dest-Port  Id  Packet-Type
-----
x.x.250.122        1645     x.x.250.111    1645       7  Access-Request
-----

User-Name : jim
User-Password : xxxxxxxxxxxx
NAS-IP-Address : x.x.250.122
```

One of the following happens:

- You receive an Access-Accept message
- You receive an Access-Reject message
- You receive no response at all

See the following table for information about what to do about responses from the security server.

Table 8 What to do about responses from the security server

Response	What to do
Access-Accept	Nothing. This indicates correct operation.
Access-Reject	Verify that the username/password are listed in user table. This indicates that the security server is receiving the Access-Request packet but cannot find the username/password in its user table. Verify that the shared secret between the client and server matches exactly.
None	Verify that the security server is receiving packets. Verify that the client and server are communicating using the same UDP port. The well-known UDP port for RADIUS authentication traffic is 1645.

Tools

- SECURITY.LOG on Total Control S/A Server—Assuming packets are making it through, this is your best source. It shows every packet that comes in.
- CLIENT.EXE included with Windows S/A Server can run from anywhere but remember you have to add that station as a client at the security server!
- LOGONT.EXE on Windows NT when using SAM database proxy
LOGONT <USERNAME> <PASSWORD> [DOMAIN]
- NETMON comes on Windows NT CD-ROM but is not installed by default. Start | Programs | Administrative Tools | Event Viewer. Will capture only those packets coming to or leaving the computer it's running on.
- DICTNARY.DAT If you don't know what a value means.
- DEBUG.LOG and ERROR.LOG (associated with third-party security servers).

Windows Log Location

- If running S/A Server as an application:
\usrsuite\security\security.log
- If running S/A Server as a service: **\winnt\system32\security.log**

UNIX Log Location

- /SA60/LOG/SASERV.LOG

If you cannot determine the cause of the problem by comparing HiPer ARC and Security server log files, insert your workstation in the routed path between them and monitor the IP packets being exchanged.

If you have a UNIX-based computer, you can run either of two freeware IP analyzers, SNOOP (for Sun computers) or TCPDUMP (for others).

Once you capture the packets, use RADDEBUG, a 3Com internal-use tool to decode them. See <http://coredump.ae.usr.com/radius/>

To capture a PPP session using NETServer

These commands capture basics of the RADIUS negotiation at the Link Control Protocol (LCP) level. For help in interpreting the results, contact 3Com Customer Support.

- 1 From a NETServer command prompt, send the commands `set debug 0x51` and then `set console`.

```
Command> set debug 0x51  
Setting debug value to 0x51  
Command> set console  
Setting CONSOLE to admin session
```

- 2 Capture the RADIUS session (save it as a text file).
- 3 Reset the console.

```
Command> reset console  
Console RESET
```


- 4 Turn off debug.

```
Command> set debug 0x00  
Setting debug value to 0x0
```

Correcting Problems


Span Alarms Red

A device experiences a red alarm when the signal it receives is not valid. A device experiencing red alarm sends a yellow alarm signal on its transmit pair.



Yellow

A device experiences a yellow alarm when it receives a yellow alarm signal. This means the device immediately upstream is not receiving a valid signal (it is experiencing red alarm).



A yellow alarm is also known as a Remote Frame Alarm (RFA).

Blue

A device experiences a blue alarm when it receives a blue alarm signal. This means the device upstream (an intermediate device, such as an intelligent repeater) is not receiving a valid signal from *its* upstream device.



The intermediate device is in red alarm, and the remote device is in yellow alarm.

A blue alarm is also known as an Alarm Indication Signal (AIS).

Telco Loopback Testing

The telco initiates loopback tests. They loop the line at the smart jack and run a standard battery of tests. This will verify signal integrity up to the demarc (point of demarcation between the telco's equipment and yours). You can set up the hub so it performs the loopback (instead of the smart jack), to check the path all the way to the hub. If the line is clean to the demarc and faulty when looped to the hub, the problem is usually with the premises wiring.

Dual PRI To resolve a RED alarm on a T1/PRI

Examine the premises wiring. Verify that the switch configuration and Total Control configuration match. Check out the cables, the Dual PRI hardware, and power. If you cannot solve the problem, report the problem to the telco and ask the telco to perform a loopback test.

To resolve a YELLOW alarm on a T1/PRI

Examine the premises wiring. If the physical connection is good, call telco.

If CRC errors are incrementing

Examine the premises wiring. Check out the cables, the Dual PRI hardware, and power. If you cannot solve the problem, report the problem to the telco and ask the telco to perform a loopback test.

If all DS0s go down simultaneously

Examine premises wiring. Check for alarm conditions. Then call the telco.

HiPer DSP To resolve a RED alarm on a T1/PRI

Examine the premises wiring. Verify that the switch configuration and Total Control configuration match. Check out the cables, the HiPer DSP hardware, and power. If you cannot solve the problem, report the problem to the telco and ask the telco to perform a loopback test.

To resolve a YELLOW alarm on a T1/PRI

Examine the premises wiring. If the physical connection is good, call the telco.

If CRC errors are incrementing

Examine the premises wiring. Check out the cables, the HiPer DSP hardware, and power. If you cannot solve the problem, report the problem to the telco and ask the telco to perform a loopback test.

If all DS0s go down simultaneously

Examine premises wiring. Check for alarm conditions. Then call the telco.

If D-channel is down

If D-channel is down, do a Q.931 trace to see whether messages are being passed at all. If not, call telco and ask them to bring up the D-channel.

Quad Modem To change line interface source

The Line interface source of the Quad (T1tdm, PRItdm, or nic) must match that of the telco access card.

- 1 Click a modem (or top LED = all modems on card; or hold [Ctrl] and select multiple modems or top LEDs).
- 2 From the **Configure** menu, click **Programmed Settings**.
- 3 From Parameter Group, select **Line Interface Options**.
- 4 From Line Interface Source, select t1Tdm, nic, or priTdm.

NETServer To join modems to the packet bus

To join modems to the packet bus, use the *set modem active* command. To interpret the results of the *show all* command, see To check whether modems are connected to the packet bus on page 40.

```
Command> show all
Command> set modem s5-s8 active
Command> save all
Command> reset s5-s8
Command> show all
```

x2 and V.90 Troubleshooting

x2 troubleshooting is covered in detail in the paper *x2: Understanding the Issues / Troubleshooting Problems*, which is available from the TotalService web site as filename **x2shoot4.pdf**.

V.90 troubleshooting is covered in detail in a paper that is to-be-determined.

Visit and search the 3Com Carrier Technical Support web site at **<http://totalservice.3com.com>**.

APPENDIX

NETServer Debug Settings

This is a complete list of debug settings for NETServer.

Table 9 NETServer debug settings

0x00	Ends debug
0x18	Logs route updates
0x51	PPP / LMI / Annex-D status
0x54	Displays the last 60 characters of in/out flow control when you issue the command show port
0x72	Watch FLASH
0x74	Last 60 characters of input/output
0x75	Last 60 characters of input/output—verbose
0x78	Telnet negotiation options
0x81	ARP updates
0x1100	Debugs RIP
0x1200	Show packet destination, type, and length

INDEX

Symbols

_authenticate HiPer ARC command 45

A

A I P, interpreting 40
A R P, interpreting 40
accepted calls 28
Access-Accept 45
Access-Reject 45
accounting
 destination, setting 20
 enabling
 chassis 23
 Dual T1/PRI 21
 HiPer DSP 20
 Quad Modem 21
 logs, checking 24
 server 20
active monitoring 24
AIS 48
alarm
 blue 48
 red
 overview 48
 resolving 49
 yellow
 overview 48
 resolving 49
Alarm Indication Signal (AIS) 48
alarm server 10, 19
AT-ADn HiPer DSP command 31
AT-AFn HiPer DSP command 28, 33
AT-SR HiPer DSP command 28
AT-SU100 HiPer DSP command 38
AT-SU99 HiPer DSP command 38
AUX port, mapping modems to 38

B

blue alarm 48
bootup failures, checking 24

C

call failure reasons
 HiPer DSP 33
 overview 11
calls accepted 28
calls received 28
capturing
 chassis configuration 16
 HiPer ARC configuration 18
 HiPer ARC PPP session 42
 NETServer configuration 18
 NETServer PPP session 42
 Windows 95/98 PPP session 43
chassis
 enabling accounting 23
 overheating 36
 temperature, checking 24
chmdm 255 HiPer DSP command 38
Citrix WinFrame 25
client.exe
 overview 12
 use 46
common logging level 39
configuration, capturing. See capturing
connect times, excessive
 checking on Dual PRI 34
 checking on HiPer DSP 26
console
 HiPer ARC 11
 HiPer DSP 11, 26
 NETServer 12
continuous CRC errors. See CRC errors, continuous
correcting problems 48
CRC errors
 checking on HiPer DSP 25
 continuous 25, 27
 resolving 49, 50
critical logging level 39

D

Data Terminal Ready signal 25
D-channel
 checking status HiPer DSP 26, 28
 errors 28

Q.931 tracing and 37
 resolving down 50

debug
 HiPer DSP overview 11
 NETServer
 complete settings for 53
 overview 12
 set debug 0xnn command 41

debug.log 46

demarc 48, 49

destination
 for accounting messages 20
 for traps 19

Dial-Up Networking
 overview 13
 PPP logging and 43

dictionary.dat 46

DIP switch settings, inventorying 15

disconnect reasons
 HiPer DSP 31
 overview 11

display atproto HiPer DSP command 29

display atstat HiPer DSP command 29

display near current HiPer DSP command 30

display near total HiPer DSP command 30

documenting the system 15

DSO
 all down simultaneously, resolving 49, 50
 in-service status, checking Dual T1/PRI 35
 in-service status, checking HiPer DSP 26, 29
 status, checking Dual T1/PRI 35

DTE interface source, checking Quad Modem 36

DTR signal 25

Dual T1/PRI
 checking CRC errors 34
 checking D-channel status 34
 checking DSO in-service status 35
 checking DSO status 35
 enabling accounting 21

E

EIA-232 25

error counts 11

error.log 46

errors
 continuous CRC 27
 HiPer DSP T1/PRI
 last 15 min 30
 last 24 hours 30

Event Viewer
 overview 13
 troubleshooting and 46

events, modem
 monitoring HiPer DSP 25
 monitoring Quad Modem 34

excessive connect times
 checking on Dual PRI 34
 checking on HiPer DSP 26

F

failures, checking bootup 24

fans, stopped 24

G

graphing results 25, 34

group number, logging 22

H

hide events HiPer ARC command 39

HiPer ARC
 capturing configuration 18
 console overview 11
 PPP session, capturing 42
 RADIUS and 44
 Syslog 39

HiPer ARC commands
 _authenticate 45
 hide events 39
 list facilities 39
 list interfaces 28, 35
 monitor ppp 43
 monitor radius 45
 set facility loglevel 39
 show events 39

HiPer ARC Product Reference 39

HiPer DSP
 call failure reasons 33
 checking D-channel status 26
 checking DSO in-service status 26, 29
 checking excessive connect times 26
 checking modem protocols 29
 console 11, 26
 disconnect reasons 31
 invalid counts 28
 modem not available count 28
 monitoring modem events 25
 Q.931 activity 37
 Reference manual 31, 33
 setting logging groups 22
 T1/PRI errors
 last 15 min 30
 last 24 hours 30

HiPer DSP commands
 AT-ADn 31
 AT-AFn 28, 33
 AT-SR 28
 AT-SU100 38
 AT-SU99 38
 chmdm 255 38
 display atproto 29
 display atstat 29
 display near current 30
 display near total 30
hub status 24

I
interface source, Quad Modem
 DTE 36
 line 36
Internet protocol 10
invalid counts, HiPer DSP 28
Inventory
 overview 10
 procedure 15
 sample 16
investigating problems 36
IP
 packets 47
 training and 10

J
jack, smart 48, 49

L
LCP 47
LEDs
 hub status 24
 Quad Modem 25
 scanning using Total Control Manager 24
 viewing 10
line interface source, Quad Modem
 changing 50
 checking 36
Link Control Protocol (LCP) 47
list facilities HiPer ARC command 39
list interfaces HiPer ARC command 28, 35
logging groups
 HiPer DSP, setting 22
 NMC, setting 22
logging level, HiPer ARC Syslog 39
logont.exe 46
logs, checking 24
loopback tests 48, 49

M
management bus 24
memory, inventorying 15
MIB browser 10
modem
 joining to packet bus 50
 mapping to AUX port 38
 mapping to packet bus 38
 not available count, HiPer DSP 28
 presence detection, NETServer 41
 protocols, HiPer DSP 29
modem events
 logging in Windows 95/98 43
 monitoring
 HiPer DSP 25
 Quad Modem 34
monitor ppp
 HiPer ARC command 43
 overview 12
monitor radius
 HiPer ARC command 45
 overview 12
monitoring
 active 24
 passive 19

N
NAC, resetting 24
NETMON
 overview 13
 troubleshooting and 46
NETServer
 capturing configuration 18
 complete debug settings 53
 console 12
 debug 41
 packet bus and 25
 PPP session, capturing 42
NETServer commands
 reset console 41
 set console 41, 47
 set debug 0x51 43, 47
 set debug 0xnn 41
 set modem active 50
 show all 28, 35, 40
Network Management Card. See NMC
NMC
 Parameter Reference manual 22
 setting logging groups 22

O
overheating 36

-
- P**
- packet bus
 - activity 40
 - connection status 40
 - joining modems to 50
 - mapping modems to 38
 - NETServer and 25
 - restoring connections 38
 - passive monitoring 19
 - Performance Monitor
 - Dual PRI
 - CRC errors and 34
 - D-channel status and 34
 - DSO in-service status and 35
 - DSO status and 35
 - HiPer DSP
 - CRC errors and 25
 - D-channel status and 26
 - DSO in-service status and 26
 - excessive connect times and 26
 - modem events and 25
 - overview 10
 - Quad Modem
 - bus interface source 36
 - events and 34
 - excessive connect times and 34
 - temperature, checking 36
 - ping 44
 - power supply unit. See PSU
 - PPP
 - capturing session
 - HiPer ARC 42
 - NETServer 42
 - Windows 95/98 43
 - for more information 44
 - logging overview 13
 - negotiation, diagnosing 43
 - Requests for Comments 44
 - PPP Monitor
 - overview 12
 - use 43
 - premises wiring 49
 - PRI. See Dual T1/PRI or HiPer DSP
 - PRIttm 50
 - problems
 - correcting 48
 - investigating 36
 - protocol
 - status 11
 - tracing
 - Q.931 37
 - tracing overview 11
 - PSU, failed 24
-
- Q**
- Q.931
 - D-channel down 50
 - errors 28
 - tracing, HiPer DSP 37
 - Quad Modem
 - DTE interface source, checking 36
 - enabling accounting 21
 - LEDs 25
 - line interface source
 - changing 50
 - checking 36
 - monitoring modem events 34
-
- R**
- RADDEBUG
 - overview 13
 - use 47
 - RADIUS 20
 - accounting messages 19
 - overview 12
 - shared secret 44
 - RADIUS monitor 12
 - received calls 28
 - red alarm
 - overview 48
 - resolving 49
 - Remote Frame Alarm (RFA) 48
 - Requests for Comments 44
 - reset console NETServer command 41
 - restoring packet bus connections 38
 - RFA 48
 - RFCs 44
 - routed path 47
 - RS-232 25
-
- S**
- saserv.log 46
 - Security and Accounting Server
 - overview 12
 - troubleshooting 44
 - security.log 12, 46
 - serial numbers, inventorying 15
 - Session Monitor. See Performance Monitor
 - set console NETServer command 41, 47
 - set debug 0x51 NETServer command 43, 47
 - set debug 0xnn NETServer command 41
 - set facility loglevel HiPer ARC command 39
 - set modem active NETServer command 50
 - shared secret, RADIUS 44
 - show all NETServer command 12, 28, 35, 40
 - show events command, HiPer ARC 39

Simple Network Management Protocol. See SNMP

smart jack 48, 49

SMS 13

SNMP

 MIB browsers and 10

 traps 19

Snoop

 overview 13

 troubleshooting and 47

software revisions, inventorying 15

span line status 27

span statistics, overview 11

status

 protocol 11

 timeslot 11

Syslog

 HiPer ARC 39

 overview 12

Systems Manager Server 13

T

T1. See Dual T1/PRI or HiPer DSP

T1tdm 50

TCM. See Total Control Manager

Tcpdump

 overview 13

 troubleshooting and 47

telco 48, 49

telnet 45

temperature, checking chassis 24

tests, loopback 48, 49

times, excessive connect

 checking on Dual PRI 34

 checking on HiPer DSP 26

timeslot status 11

Total Control chassis. See chassis

Total Control Manager

 Inventory function 15

 overview 10

 passive monitoring and 19

 scanning LEDs and 24

totalservice.3com.com 51

tracing

 overview 11

 Q.931 37

training, modem 25

traps

 enabling

 HiPer DSP 19

 NMC 19

 PRI 20

 in overview 10

 passive monitoring and 19

 setting destination 19

 troubleshooting 20

troubleshooting

 traps and 20

 V.90 51

 x2 51

U

UDP/IP 19, 20

unusual logging level 39

V

V.90 troubleshooting 51

verbose logging level 39

VFPD. See virtual front panel display

virtual front panel display 10, 24

W

Windows 95/98

 modem event log 43

 overview 13

 PPP session, capturing 43

Windows NT 46

wiring, premises 49

X

x2 troubleshooting 51

Y

yellow alarm

 overview 48

 resolving 49